


## CHAIN SAW SAFETY

### EIGHT MOST COMMON CAUSES OF CHAIN SAW INJURY

1. Gripping saw handles improperly
2. Not watching the bar tip and letting it touch other objects, causing kickback
3. Cutting overhead
4. Letting helpers work near the saw
5. Cutting from a ladder or a tree
6. Cutting near brush, limbs, rocks, metal, or power lines
7. Forcing a pinched bar from the cut with the engine revved
8. Letting the saw bar move away from the last cut before the coasting chain has stopped



# CHAIN SAW SAFETY

## BASIC TECHNIQUES

### Basic Working Position and Technique

