



WRITTEN QUIZ

Procedures Handbook 4300

PROCEDURES USED TO CLEAN AND SANITIZE SELF-CONTAINED BREATHING APPARATUS

NAME: _____

DATE: _____

POINTS

1. Cleaning your face piece on a regular basis may prolong the life of your face piece. 10
True False

2. What should you use to clean your SCBA face piece? 10

3. Why do you not dry the face piece in direct sunlight? 10

4. When cleaning your SCBA Face mask you should not only clean the mask but _____ it for any other problems. 10

5. How do you dry your face mask when cleaned? 10

6. It's ok to submerge your face mask into a cleaning solution if it's not equipped with a voice amplification device. 10
True False

7. Paper towel are good for drying your face mask lens. 10
True False

8. It is ok to submerge your regulator in the cleaning solution. 10
True False

9. Your harness, hoses, and regulator need cleaning after each use. 10
True False



WRITTEN QUIZ
Procedures Handbook 4300

PROCEDURES USED TO CLEAN AND
SANITIZE SELF-CONTAINED BREATHING
APPARATUS

POINTS

10. What should you look for while cleaning your SCBA harness, hoses and regulator? 10
-

POINTS POSSIBLE: 100

POINTS DEDUCTED:

FINAL SCORE:



KEY

POINTS

1. Cleaning your face piece on a regular basis cleanse and sanitize your face piece. 10

TRUE False

REF. TLP, pg. 2, sect. II, notes

2. What should you use to clean your SCBA face piece? 10

**A MILD SOLUTION WITH WARM WATER AS PER
MANUFACTURER'S SPECIFICATIONS**

REF. TLP. pg. 2, sect. II, B-1

3. Why do you not dry the face piece in direct sunlight? 10

**DIRECT SUNLIGHT WILL DETERIORATE THE RUBBER
COMPONENTS**

REF. TLP. pg. 3, sect. II, F-1, sect. III, D-1

4. When cleaning your SCBA Face mask you should not only clean the mask but **INSPECT** it for any other problems. 10

REF. Information Sheet #1

5. How do you dry your face mask when cleaned? 10

AIR DRY

REF. TLP. pg. 3 sect. II, F, sect. III, D

6. It's ok to submerge your face mask into a cleaning solution if it's not equipped with a voice amplification device. 10

TRUE False

REF. TLP. pg. 3 sect. III, A

7. Paper towels are good for drying your face mask lens. 10

True **FALSE**

REF. TLP, pg. 2, sect. I, D.

8. It is ok to submerge your regulator in the cleaning solution. 10

True **FALSE**

REF. TLP. pg. 4, sect. V, B-5

9. Your harness, hoses, and regulator need cleaning after each use. 10

TRUE False

REF. TLP. pg. 4, sect. V, A, B, sect. VI, A through C



WRITTEN QUIZ
Procedures Handbook 4300

PROCEDURES USED TO CLEAN AND
SANITIZE SELF-CONTAINED BREATHING
APPARATUS

KEY

POINTS

10. What should you look for while cleaning your SCBA harness, hoses and regulator? 10

EXCESSIVE DIRT, HEAVILY SOILED

REF. TLP, pg. 4, sect. IV, A. – C.

POINTS POSSIBLE: 100

POINTS DEDUCTED:

FINAL SCORE: